




HAYHOUSE™ BLIND

Patent Pending

Instruction Manual




Be sure to follow these guidelines for using your Hayhouse™
READ ALL INSTRUCTIONS and WARNINGS FIRST

Any questions or confusion regarding the use of this product contact our
Customer Service Department at Ameristep® (810) 686-4035 before using.

COMPONENTS

HAYHOUSE™ BLIND



- A. Top Roof Opening
- B. Door Zipper
- C. Tie-Down Loops (4 included)
- D. Stake Loops (8 Stakes Included)
- E. Integral Brush Pockets
- F. Fiber Pole Roof Supports



PARTS/FEATURES LIST:

- 1 Hayhouse™ Blind
(60" wide x 60" Long x 60" high)
- 8 Steel Stakes
- 8 Plastic Stakes
- 4 high wind tie-downs
- Integral Brush Pockets
- Rip cord Release opens top third of Blind
- 1 Camo Backpack




THINK SAFETY !

- NEVER USE A HEATER IN YOUR HUNTING BLIND - UNVENTED FUMES COULD CAUSE SICKNESS OR DEATH
- NEVER EXPOSE YOUR BLIND TO ANY OPEN FLAME. THIS PRODUCT IS NOT FIREPROOF.
- NEVER ALLOW CHILDREN TO PLAY WITH THIS PRODUCT WITHOUT ADULT SUPERVISION.
- NEVER ALLOW THE MATERIAL TO COVER YOUR FACE. IT CAN CAUSE SUFFOCATION AND DEATH.

STORAGE & TIPS

- Store your Blind in a cool dry place
- Store your Blind free of dirt and any debris
- Never store your Blind wet or damp
- Avoid leaving your Blind outdoors for extended periods of time as it will cause unnecessary fading of the material if left in direct sunlight.
- To stop any leakage, use seam sealer on all seams and silicon spray on the sidewalls.



ACCESSORIES AVAILABLE:



High-Back Camo Chair



NEW! Blind Bench



Archer's Chair



Directors Chair

See our full line of accessories on our website.
Replacement Parts are also available

SET-UP

HAYHOUSE™ BLIND

! Tip

Make sure you allow plenty of room for your Hayhouse™ to open.

NOT RECOMMENDED TO SET UP INDOORS.




WARNING: The Hayhouse™ Blind is constructed of Spring Steel - Open with extreme caution, holding the blind away from face, body and other people.



Step 1:

Remove the stake and tie-down pouches from the backpack. Remove the Hayhouse™ from the backpack. Hold with both hands.




Step 2:

(A) Carefully allow the spring steel to slowly unfold.

(B) The two 5' diameter circular panels will pop out.


(C) The material between the 2 circular panels form the side panels. Once it has popped open, spread the sides out.



Step 3:


ATTACHING THE ROOF POLE:

Install the gray roof pole into the gray pockets in the top of the blind. Hook the loop fastener around the support pole in the middle of the roof.



! Tip

For ease of installation, the fiber poles and corresponding pockets are color coded.



Step 4:

Attach the brown diagonal side poles to opposite corners on the sides of the blind, inserting the pole ends into the the brown pockets. The poles should run from top to bottom corner to form an "X".

Step 5:

Attach the green vertical side poles into the black pockets so that they intersect with the diagonal poles in the center of the side panels. Then fasten all three on each side at their juncture with the ties sewn onto the side panels.



ATTACHING THE ROOF FLAP POLES:

(A) Attach the black fiber pole to the roof flap using the black pockets and the hook and loop fastener.

(B) Drape the roof flap over the top of the blind as shown.

(C) From the inside of the blind, attach the rip cord to the top center black roof flap pole with the hook and loop fastener.

TAKE-DOWN HAYHOUSE™ BLIND


IMPORTANT:

BEFORE take-down of your Hayhouse™, remove all fiber poles, high wind tie-downs and ground stakes. Make sure that it is **COMPLETELY DRY** and free from dirt and any debris.

Step 1: Remove all fiber poles, high wind-tie-downs and ground stakes. Zip all openings before Take-Down.



Step 2: Take hold of one of the corners and lay the blind on its side.



Step 3: Grasp the blind at 10:00 and 2:00, keeping knuckles up and thumbs underneath.

Roll the blind away from your body. Tuck under the "Nose", a "U" shape will begin to form.



Step 4:

Once a "U" shape has formed, remove one hand from the blind and reverse its position so that the knuckles are on the inside of the "U" and the thumb on the outside.



Step 5:

Continue to roll the portion which you are grasping towards your body. Tuck it under so that it overlaps the bottom part of the blind.



Step 6:

On one side of the portion you are folding under, a smaller, circular bundle comprised of two steel bands will form.

This smaller circle will overlap the portion being tucked under, forming a folded bundle approximately 6" thick by 30".

! Tip



Integral brush pockets accept grasses and plants to enable hunters to match the Hayhouse™ blind to their surroundings.

Pack ground stakes, and high wind tie-downs in the pouches provided. Store them with your Ameristep® Blind for your next hunting adventure.

